

4.3.1 SECTION A - AIRFRAME SECTION: Applicable to Eurocopter Model AS350 B3 Maintenance Program (Continued)

SECTION	FREQUENCY
A 4111 RT	Every 5400 Hours, Restricted Tolerance to 300 Hours
A 5010	Every 7 Days
A 5090	Every 30 Days
A 5210	Every 3 Months
A 5330	Every 6 Months
A 5450	Every 12 Months
A 5611 NT	Every 24 Months, No Tolerance
A 5850	Every 48 Months
A 5851	Every 48 Months
A6031 RT	Every 72 Months, Restricted Tolerance to 6 Months
A6032RT	Every 72 Months, Restricted Tolerance to 6 Months
A6033RT	Every 72 Months, Restricted Tolerance to 6 Months
A6034RT	Every 72 Months, Restricted Tolerance to 6 Months
A6035RT	Every 72 Months, Restricted Tolerance to 6 Months
A6036RT	Every 72 Months, Restricted Tolerance to 6 Months
A6037RT	Every 72 Months, Restricted Tolerance to 6 Months
A6051 RT	Every 144 Month, Restricted Tolerance to 6 Months

4.3.2 SECTION B - POWERPLANT SECTION: Applicable Eurocopter AS350 2B/2B1 engine

SECTION	FREQUENCY
B 0110	Every 20 Hours
B 0230	Every 30 Hours
B 0330	Every 50 Hours
B 0810	Every 200 Hours
B 1030	Every 300 Hours or 6 Months whichever comes first
B 1611 RT	Every 600 Hour, Restricted Tolerance to 50 Hours

4.3.3 SECTION C - INSTRUCTIONS FOR CONTINUED AIRWORTHINESS: Applicable to Eurocopter Model AS350 Series ICA's.

SECTION	FREQUENCY
C 0001	Every 12 Months
C 0002	Every 24 Months
C 0330	Every 50 Hours
C 0520	Every 100 Hours
C 0521	Every 100 Hours
C 0540	Every 100 Hours or 3 Months whichever comes first
C 0560	Every 100 Hours or 12 Months whichever comes first
C 0810	Every 200 Hours