

4.3 SCHEDULE OF INSPECTIONS**4.3.1 BASIC INSPECTIONS: Basic Inspections Applicable to DHC-6 Series Aircraft**

SECTION	TYPE	FREQUENCY
R A007	Routine A	Every 7 Days
R E007	Routine B	Every 7 Days
B 0125	Basic	Every 125 Hours
B 0250	Basic	Every 250 Hours
C 0500	Basic	Every 500 Hours
C 1000RT	Basic	Every 1000 Hours
C 1500RT	Basic	Every 1500 Hours
C 1700NT	Basic	Every 12 Months
C 3000RT	Basic	Every 3000 Hours

4.3.2 POWERPLANT INSPECTIONS: Powerplant Inspections Applicable to Pratt & Whitney PT6B-34 Series Powerplant

SECTION	TYPE	FREQUENCY
P 0100	Powerplant	Every 100 Hours
P 0400	Powerplant	Every 400 Hours

4.3.3 FUNCTIONAL INSPECTIONS: Functional Inspections Applicable to DHC-6 Series Aircraft

SECTION	TYPE	FREQUENCY
F 3000NT	Functional	Every 3000 Hours

4.3.4 COMPONENT TESTS: Component Tests Applicable to DHC-6 Series Aircraft performed Off Wing

SECTION	TYPE	FREQUENCY
CT 6000NT	Component Test	Every 6000 Hours