

TABLE OF CONTENTS

Subject	Chapter	Page
INTRODUCTION		1
General		1
Structural Life Limits		1
Main Differences, Aircraft Series		1
Revisions		1
INSPECTION REQUIREMENTS		
General		1
Basis for Requirements		1
Scope		1
Contents of Manual		1
Supporting Reference Documents		2
Definitions		2
Inspection Programs		3
Inspection Programs (Standard)		3
Inspection Programs (EMMA Controlled)		4
Low Utilization Maintenance Program		7
Other Than Assumed Utilization		7
High Intensity Radiated Fields (HIRF)		7
Revisions		7
PART 1 – BASIC INSPECTION REQUIREMENTS		
Air Conditioning	21	1
Auto Flight	22	1
Communications	23	1
Electrical Power	24	1
Equipment/Furnishings	25	1
Fire Protection	26	1
Flight Controls	27	1
Fuel System	28	1
Hydraulic Power	29	1
Ice and Rain Protection	30	1
Instruments	31	1
Landing Gear	32	1
Lighting	33	1
Navigation	34	1

Oxygen	35	1
Pneumatic	36	1
Cabin Systems	44	1
Doors	52	1
Fuselage	53	1
Nacelles	54	1
Stabilizers	55	1
Windows	56	1
Wings	57	1
Propellers	61	1
Power Plant	71	1
Engine	72	1
Engine Fuel and Control	73	1
Engine Controls	76	1
Engine Indicating	77	1
Oil	79	1
Starting	80	1

PART 2 – SPECIAL INSPECTION REQUIREMENTS

SP1 - Environmental Conditions

A. Unpaved Landing Fields	1
B. Arctic Condition	
C. Salt Water Float Operation	2
D. Converting to Wheels or Skis	3
E. High Salt Content or Marine Environment (Outside of the Tropics) (Floatplane and Landplane)	4
F. High Industrial Air Pollution	5
G. Desert or High Dust Content Areas	6
H. High Humidity	7
I. Tropical High Salt Content or Tropical Marine Environment (Between the Tropics of Cancer and Capricorn) (Floatplane and Landplane)	

SP2 - Non-Environmental Conditions

A. Landing Gear	1
B. Fuel System	
C. Flight Controls	2
D. Wings	3
E. Empennage	5

CONTENTS

F. Fuselage	6
G. Engine and Propeller	7
H. Furnishing	8
I. Autopilot	
J. Fire Protection	9
K. Oxygen	10
L. Navigation	
M. Autoflight	
N. Indicating & Recording Systems	
SP3 - Operational Conditions	
A. Livestock or Corrosive Cargo	1
B. Wheel Ski Operations	2
C. Spring Ski Operation	8
D. Float Operations	9
E. Inspection After Heavy Landing	11
F. Lightning Strike Inspection	14
G. Severe Turbulence or Buffeting Inspection	19
H. Ground Gust Condition Inspection	21
I. Hot End Inspection	24
J. Regular Rough Water Operation	25
K. Volcanic Ash Encounter	
L. Cold Weather Operations Kit	26
SP4 - Special Conditions	
A. Aircraft Serial Number Specific	1
PART 3 – STRUCTURAL COMPONENT SERVICE LIFE LIMITS – SUPPLEMENTARY INFORMATION AND PROCEDURES	
General	1
Structural Component Service Life	
“Severe” and “Light” Definitions	
“Severe” and “Light” Conditions	2
Data on Specific Operations	
Pre Mod 6/1117 Wing-Spar, Strut-Lug, Fastener Hole Inspection Procedure	
Fail-Safe Inspection	13
Structural Inspection for Cracks	14
Wings Post Mod 6/1117	
Flaps, Series 1, 100, 200 landplanes only	
Nacelles, Series 300 and 400 only	

Special Inspection for Cracks

Inspection of Lower Wing Skins, Stringers and Aft Spar
Lower Flange for Cracking

21