


Chapter 71 – Power Plant

ITEM NO.	DESCRIPTION	FUNCTION	IDENTIFICATION
1	Wrench	Used on engine mounting securing bolts during removal and installation of engine	SD12524–1
2	Engine build-up dolly c/w towbar	Used to service and transport an engine	SD12530–1
3	Towbar	Used to tow engine build dolly (included with item 2)	SD12531–1
4	Engine sling (A-A)	Used to hoist complete quick engine change unit with or without propeller	SD12541–1
5	Engine sling (A-G)	See item 4	SD12541–3
6	Sling	Used to hoist engine power section complete with propeller	CPWA30338
-7	Bracket	Installed at front end of engine to facilitate removal of hot end c/w propeller; used with item 6	CPWA3004742
-8	Engine/propeller hoist	Used to hoist propeller and complete engine	92275A (Field Aviation)



Ground Support Equipment – Power Plant
Figure 13

PART 2